




FRAMING NOTES:

1. CT-STUDS TO BE CUT $\frac{3}{4}$ " LESS THAN THE SPAN LENGTH BETWEEN THE TOP AND BOTTOM J-TABBED TRACKS.
2. FACE LAYER OF GYPSUM BOARD MUST BE APPLIED IN THE HORIZONTAL ORIENTATION TO EACH STUD FLANGE AND INSTALLED USING MINIMUM #6 TYPE S DRYWALL SCREWS SPACED A MINIMUM OF 12" O.C. TO THE FRAMING MEMBERS. ADDITIONAL LAYER (IF REQUIRED) TO BE APPLIED VERTICALLY & OFFSET TO ENSURE THAT JOINTS WILL NOT ALIGN WITH INITIAL LAYER OF BOARD.
3. REFERENCE ClarkDietrich SHAFTWALL SYSTEM TECHNICAL CONTENT ON www.clarkdietrich.com FOR TYPICAL INSTALLATION PROCEDURES.

1 SHAFTWALL FRAMING SECTION

TYPICAL ClarkDietrich CT-STUD SHAFTWALL



ClarkDietrich
BUILDING SYSTEMS

Engineering Services: (877) 832-3206

Technical Services: (888) 437-3244

The CAD detail library is intended to provide general framing details only and does not replace the judgments and designs of a qualified architect and/or engineer. The details are provided as a starting tool to assist the user in creating and detailing cold-formed steel framing construction details. Each detail including accompanying text must be thoroughly evaluated and approved by a qualified architect or engineer. | Find over 500 CAD details at cad.clarkdietrich.com | © Copyright 2015 ClarkDietrich Building Systems